

**PRESENTATION:**  
**CE 4412 LECTURES**

**ONSITE SANITATION AND FAECAL  
SLUDGE MANAGEMENT**

By

J. M. Tembo

SEPTEMBER 2021

# Objectives

- ❖ Introduce students to OSS
- ❖ Introduce students to FSM

# Definition

- ❖ A system where the treatment of excreta or sewage or wastewater takes place at the site of generation
- ❖ It is also referred to as decentralised sanitation system

# Significance

- ❖ Appropriate system where the per capita investment in terms of off-site is too high (Example-farm areas with spaced housing units)
- ❖ Also may be the only feasible sanitation means in poor communities (In poor countries)
- ❖ May be the only feasible sanitation means in areas with a hostile geology

# Significance



- ❖ In Lusaka, over 70% of the population is in peri-urban areas where more than 90% are on pit latrines
- ❖ Most of the other areas are on septic tanks
- ❖ Sewered area are less than 20%

# On-site Sanitation Systems


- ❖ Conventional On-Site Systems (Drop and Store)
- ❖ Resource Oriented Sanitation - ROSA (Ecological Sanitation)

# Types of Conventional On-site Systems

- ❖ Simple Pit Latrines
- ❖ Ventilated Improved Pit (VIP) latrines
- ❖ Water flush toilets connected to septic tanks
- ❖ Aqua-privies
- ❖ Cesspools
- ❖ Cartage or Conservancy or bucket Latrines



# Conventional Pit Latrines




- ❖ WHAT IS IT?
- ❖ Simplest method of sanitation.
- ❖ An on-site disposal system without any effluent-**Only seepage**
- ❖ Used in villages and peri-urban areas



# Conventional Pit Latrines: Construction and Operation aspects

- ❖ Consists of a pit in the ground with some superstructure for privacy.
- ❖ Hole can be lined (unstable soils)
- ❖ At least, **the bottom should not be lined** to allow for seepage
- ❖ Should normally be constructed in areas where:
  - ✓ The geology is not rocky
  - ✓ Groundwater table is not high
  - ✓ Water sources are not in the immediate vicinity (>15 to 30m down hill of a water source???)



# Conventional Pit Latrines: Construction and Operation aspects

❖ Will have a superstructure for privacy



❖ Should have a squatting slab or pedestal

Source: USAID





Figure 1. Squatting Slab



Hazard  
Isolated?



# Problems With Conventional Pit Latrines



- ❖ Odour, flies

- ❖ Overflowing pits, no space to dig new pits

- ❖ Pit latrines have to be outdoors (safety issues)



- ❖ No means of emptying pits

- ❖ Groundwater contamination

# Pit Latrine Operational aspects

- ❖ When **about 2/3 to 3/4 full**, it should be decommissioned.
- ❖ Should be filled with earth and replaced by a new pit (where land is adequate). Otherwise it should be emptied – Refer to FSM Section
- ❖ The opening **should be kept covered** when the facility is not in use (Awareness required).

# Pit Latrine Operational aspects

- ❖ Designing of a latrine:
  - ❖ Estimate Sludge Accumulation Rate (SAR) (40 to 60 litres/cap.y)
  - ❖ Decide period required before replacement or emptying
  - ❖ Demographic data (Household population)
  - ❖ Then volume can be computed (Take cognisance of the fact that pit latrines are also receptors of solid waste in most cases)



# The Ventilated Improved Pit (VIP) Latrine

❖ Has special features to reduce odour and flies

## ODOUR REDUCTION


- Vent pipe (Maximum exposure to sun) and above roof level for air movement
- Colour of vent pipe should be black
- Vented door
- No closing of squatting hole

## FLY REDUCTION

- Painting of the inside of toilet-Black
- Screen on vent pipe




# The Ventilated Improved Pit (VIP) Latrine



## Dry on-plot systems

### Ventilated Improved Pit (VIP) toilet






# VIP Operational aspects (As for pit latrines)

- ❖ When there is no intention to use the accumulated faecal sludge, it should be buried when about 2/3 to 3/4 full.
- ❖ Should be filled with earth and replaced by a new pit.
- ❖ Should be sited about 30m from water sources like wells
- ❖ Where it has to be emptied Refer to FSM Section

# Septic Tank: What Is It?

- ❖ A water tight settling tank in which wastes, usually from individual households, are flushed down a short sewer.
- ❖ Suitable for areas with adequate water supply but no sewerage system



# Septic Tank: Sitting

- ❖ To be used in areas with low ground water table and where the geological formation is not porous (Because the effluent from the tank goes to a soakaway for infiltration into the ground)
- ❖ To be positioned at least 3m from water pipes
- ❖ Suitable in low density areas
- ❖ Should be located away from water sources (>30m from water wells; 7m from rivers, 3m from water pipes).....check Water Resources SI (50m)

# Septic Tank: Design and Operations

- ❖ Designed with a retention time of about **3 days** which should not go below 1 day
- ❖ Water depth about **1-2m**
- ❖ Should have **at least two** compartments in the ratio 2:1
- ❖ Inlet pipe (Tee) discharges **downwards** to avoid short circuiting (And to prevent scum going out)
- ❖ Partition wall perforated or open jointed a depth below water surface (This prevents scum from floating into second chamber)
- ❖ Discharge pipe is **Tee to avoid scum** floating to soakaway or drainfields (Avoid clogging)

# Septic Tank: Design and Operations

- ❖ Usually, desludged once in 3 – 5 years (Need to know the average **Sludge Accumulation Rate** (SAR: 40 to 60 L/C.Year))

# Septic Tank: Treatment Mechanism

- ❖ Treats solids anaerobically
- ❖ Liquid discharged into the ground via **soakaway** or **drainfields** where it gets treated through the process of filtration and other biological processes.

# Septic Tank: Design and Operations

## QUESTION:

Design a septic tank for a family of 10 people in Meanwood Ibex hill

## SOLUTION


- ❖ Compute hydraulic loading
- ❖ Choose retention time

## WHEN TO DESLUDGE

- ❖ SAR = 40 to 60 liters/c.year
- ❖ Decide minimum hydraulic retention time at time of desludging – Usually one day





# Soakaway




- ❖ Purpose is to aid infiltration of wastewater into the natural ground
- ❖ Consists of a circular or square walled-up hole in the ground
- ❖ Top 0.3-0.5m should be water-tight
- ❖ Lower part should be an open-jointed wall.
- ❖ Performance is dependant on **soil characteristics** and **efficiency of the Septic Tank** (Percolation test result: **15 to 100 seconds/mm drop**)

# Drain fields




- ❖ Consists of **trenches** in series and parallel arrangement
- ❖ Each trench consists of an open jointed pipe
- ❖ Pipes are laid on rock fill or gravel fill then covered with earth
- ❖ Used where quantity of water to be infiltrated is huge (E.g. block of flats)

# AQUA-PRIVIES (Pour Flush)



- ❖ A modified septic tank-  
1-2 m<sup>3</sup>
- ❖ Filled with water and  
directly below  
squatting pan.
- ❖ consists of a watertight  
concrete tank
- ❖ comparatively lower  
water requirements as  
compared to the septic  
tanks.
- ❖ Suited to areas without  
adequate water supply  
in the house

# AQUA-PRIVIES (Pour Flush)



# CESSPOOLS/CESSPIT

- ❖ A covered chamber with no overflow receiving and storing all the wastewaters from a dwelling or dwellings.
- ❖ Frequency of emptying is high and as such, this system has high operating costs.

# Cartage or Conservancy or Bucket Latrines

- ❖ One of the oldest systems for excreta collection
- ❖ A bucket receives the excreta, (nightsoil).
- ❖ Bucket usually placed in bucket chamber directly under a squatting slab and is accessible through a back door from the street.




Figure 5.7 Bucket for bucket latrine




Figure 5.8 Superstructure for bucket latrine

bucket.

Source: Google Images

# Bucket Latrines: Operational Challenges

- ❖ Very difficult to operate in a hygienic way.
- ❖ Flies are a problem.
- ❖ Spillage occurs easily when the latrine is used and when the bucket is removed, emptied and replaced.
- ❖ Transport and disposal of the excreta may be connected with health hazards.




# FAECAL SLUDGE MANAGEMENT

- ❖ FSM is the storage, collection, transportation, treatment and safe enduse/disposal of Faecal Sludge  
(See sanitation service chain below)
- ❖ New field that has evolved due to the realisation that OSS are not complete without a functional FSM.
- ❖ Faecal Sludge: Excreta which comes from onsite facilities and has not been transported through a sewer  
(Strande et. al., 2014)

# Faecal Sludge Management

## Sanitation service chain



CAPTURE

CONTAINMENT

EMPTYING &  
TRANSPORT

TREATMENT

SAFE REUSE OR  
DISPOSAL

# FSM: Captute and Storage or Containment

❖ Capture is by interface

JMP  
— Built to Measure —  
www.jmpsoftware.com



# Interface: Considerations

- ❖ Needs to be user friendly



- ❖ Needs to respond to end-use requirements



Source: Google Images



# FSM Challenges - Emptying

WHEN LATRINE GETS FULL  
– WHAT NEXT



CONSEQUENCES  
IF INAPPROPRIATE

- Degraded living conditions
- High morbidity and mortality rates





# FSM: Emptying and Transportation

Manual



Mechanical



Manual-Modified Garden Tools



Manually operated mechanical System (Gulper; Diaphragm; Mappet etch)





# FSM: Transportation

## Mechanical



## Push Carts





# Emptying and Transportation: Considerations

- ❖ Accessibility of sites (Where inaccessible, then manual means are appropriate)
- ❖ Quality of faecal sludge (High Solid waste content results in desludging difficulties, Rheological properties: The thicker the sludge, the more difficult it is to pump out)



# FSM: Treatment

- ❖ Faecal sludge will be highly concentrated
- ❖ Mostly anaerobic treatment systems are employed (Suitable for strong sludge)
- ❖ Drying beds (Unplanted and Planted) can be also be used separately or in combination
- ❖ Co-treatment at conventional plants can also be used (Need to take care not to over load treatment plants)





# FSM: Reuse and Disposal/Resource Oriented Sanitation – The Omni Processor



# Products from an Omni Processor

## ❖ Characteristics of an Omni Processor Plant

- Treats up to 16.8t/day sludge with MC =0.4g/g dry sludge
- Produces up to 3.6MW of electricity in 24 hours
- Produces 26.4m<sup>3</sup> of water/day (demineralised)
- Produces 9.6m<sup>3</sup> of ash in 24 hours





# FSM: Reuse and Disposal/Resource Oriented Sanitation



FS Briquettes



FS Fertiliser



Black Soldier Flies

# Reuse Of Faecal Sludge/Excreta Products Comparative Results



Source: Hakan, 2004



# Pictorial Evidence: Rwanda



(Source: Håkan, 2004)

# The fertigative effects of urine

Plant, growth period and number of repetitions n	Unfertilized plants g	Fertilized, 3:1 water/urine application 3x per week g	Relative yield fertilized to unfertilized
Lettuce, 30 days (n = 3)	230	500	2.2
Lettuce, 33 days (n = 3)	120	345	2.9
Spinach, 30 days (n = 3)	52	350	6.7
Covo, 8 weeks (n = 3)	135	545	4.0
Tomato, 4 months (n = 9)	1680	6084	3.6

(grams fresh weight) in plant trials with urine as a fertiliser to vegetables in Zimbabwe (Morgan, 2003)



# Fertigative effects of excreta compost

Plant, soil type and number of repetitions	Growth period	Fresh weight topsoil only g	Fresh weight 50/50 topsoil/ FA*soil g	Relative yield fertilized to unfertilized
Spinach, Epworth soil (n = 6)	30 days	72	546	7 .6
Covo, Epworth soil (n = 3)	30 days	20	161	8 .1
Covo 2, Epworth soil (n = 6)	30 days	81	357	4 .4
Lettuce, Epworth soil (n = 6)	30 days	122	912	7 .5
Onion, Ruwa soil (n = 9)	4 months	141	391	2 .8
Green pepper, Ruwa soil (n = 1)	4 months	19	89	4 .7
Tomato, Ruwa soil	3 months	73	735	10 .1

\* *Fossa alterna* soil

**Average yields (grams fresh weight) in plant trials comparing growing in poor topsoil only, with growing in a mixture consisting of 50% topsoil and 50% Fossa alterna compost (Morgan, 2003)**

END

THANK YOU